

# RAISED GARDEN BED

## ASSEMBLY GUIDE

The YARDFULLY™ Raised Garden Bed is made from high-strength flexible HDPE materials, which provides a stable structure for your raised beds while also allowing customizable shapes and contours. The Yardfully Raised Garden Bed is fast and easy to set up, and typically requires no tools for assembly.



### MATERIALS INCLUDED IN KIT:

- (2) Raised bed HDPE strips (each strip is 6 inches wide by 12 feet long)
- (2) Closure keys
- (12) Stakes

### RECOMMENDED SOIL MIXTURE (not included):

- 1 Part = Potting Soil
- 2 Parts = Compost (from your Yardfully GEOBIN® Composter or home compost system)
- 3 Parts = Topsoil

### RECOMMENDED TOOLS:

- Rake or shovel for surface preparation (as needed)
- Work gloves

1

#### Prepare the surface for installation

- Find your ideal location.
- Level the existing ground, if necessary.

2

#### Assemble the raised garden bed

- Remove the raised garden bed strips from the box.
- Roll out the strips and lay them flat on the ground. If necessary, allow the strips to lay in the sun for a few hours. This will allow the material to relax and release residual curl.
- Once expanded, turn the strips upright and adjust to your preferred shape.



3

### Connect and secure the strips

- Connect and secure the strips by inserting the closure keys through overlapping I-slots on each end.
- Install keys so that the larger key handle is on the outside of the strips.
- Turn each key 90 degrees to lock it into place.



4

### Stake down the strips

- Angle the U-stakes so the vertical sections are in direct contact with both sides of the strip.
- Typical stake spacing is 24 inches (and at corners as necessary to achieve the desired shape/contours).



5

### Infill the raised bed

- For superb flower, fruit, or vegetable growth, the recommended infill material ratio is:
  - 1 Part = Potting Soil
  - 2 Parts = Compost
  - 3 Parts = Topsoil

